

Einbauanleitung

Basis Boost Inc. Smart Cooler BoostBox

System	Enthaltene Komponenten
Vensells OL	Castles UPT1000F + OL-Modul
Vensells CL	CL-Reader + Vencube, keine Telemetrie-Anwendung!

Bitte Firmware-Version beachten!

Green box



MDB - Karte
Y - Kabel

CLOSED LOOP

Vencube



MDB

Version: 20.09



CL-Reader

OPEN LOOP

OL-Modul



MDB

Version: 1.48

MDB^A
Power

RS232^B
Serielles Kabel

Ethernet / LAN^C



Castles UPT1000F

EVA-Einstellung Vencube:

EVA	Beschreibung
MA5*CDS*3*3*1	Vensells CL
MA5*GW99*2	Keine Kreditsysteme
MA5*GW120*1*0*0*2*0*3*0*0	Nur als Kartenleser zum Automaten melden
MA5*CL2*0*0	Cashless Adresse #1

EVA-Einstellung OL-Modul:

EVA	Beschreibung
MA5*CL2*1*1	Cashless Adresse #2
MA5*AWI*1*1	Always Idle